



CHINESE PORK BUNS

HEATING INSTRUCTIONS:

If frozen, defrost in refrigerator overnight.

1. Preheat oven to 350° F (350° F convection).
2. Transfer pork buns to a lined baking sheet and cover with foil.
3. Bake for 20 minutes, then remove from oven and allow buns to rest for 5 minutes while still covered.

BON APPETIT!

***For food safety, all hot items should be heated to a minimum of 165° F**

**** Consume or freeze dishes on or before expiry date**